

**REF**

12-1220/12-1221/12-1222

**BASELINE<sup>®</sup>** EVALUATION  
INSTRUMENTS

## Finger Circumference Gauge



**To measure the  
circumference of  
a joint or digit:**

1. Wrap webbing around finger or joint.
2. Thread webbing through slot and align excess webbing across ruler.
3. Record measurement along ruler at end of webbing. This is the circumference.



Fabrication Enterprises Inc.  
250 Clearbrook Rd, Suite 240  
Elmsford, NY 10523 (USA)  
tel: +1-914-345-9300  
fax: +1-914-345-9800  
FabEnt.com



Authorized CE representative:  
AJW Technology Consulting GmbH  
Königsallee 106  
40215 Düsseldorf (Germany)

©2021 FEI, all rights reserved.  
Baseline is a registered  
trademark of Goldberg. v0821