

Peg-Assist™ Instruction Card



Remove black insole.



Insert Peg-Assist™ Insole.



Circle off-loading site.



Imprint on blue side.



Remove pegs
beneath marking.*

Rev. 909



Attach stabilizer
board to peg side.
(Peel white paper to reveal adhesive)



Reinsert Peg-Assist™ Insole.

*To avoid risk of tearing top layer of Poron, please remove pegs slowly.



Done!