


13008



- 1. Hardware- 13008H
- 2. Locking Caster- 13007CL
- 3. Base- 13008HB
- 4. Non-Locking Caster- 13007C
- 5. Adjustable Mast- 13008AM
- 6. Plastic Bushing- 13008B
- 7. Adjustment Knob- 13008K
- 8. Adjustment Bolt Bushing- 13008AB
- 9. Elevating Lever- 13008EL
- 10. Adjustment Bolt- 13008AAB
- 11. Table Top- 13008-T
- 12. Table Mounting Bracket- 13008TB
- 13. Caster Plug- 13008CP

Included with # 1