


A) Measure the circumference of the IP joint.

B) Measure the distance on the palm surface from the IP joint to the proximal end of the thenar crease.



All measurements are in centimeters