

LAKESIDE[®]

Ingenuity On Wheels[™]

Lakeside 8190 PlusPower Platform Truck, 27 x 60-in. Platform, 1,500-Lb. Capacity



lakeside.com/foodservice/product/pluspower-platform-truck-27-x-60-platform-1500-lb-capacity

SKU: 8190



Reduce injury and increase efficiency with these hard working platform trucks. Ergo-One[®] Plus Power carts are the most versatile battery operated carts available. Ergonomically designed, these carts feature the exclusive Ergo-One drive system and Intuitive Finger Tip Controls with load capacities up to 1,500 lbs. (680 Kg) on a level surface and 1,000 lbs. (680 Kg) on a 6 degree incline. Bolt, weld, or clamp on your current equipment and transport carts to the steel platform of the Lakeside Ergo-One[®] Plus Power carts to create your own custom carts. Ergo-One Plus Power carts feature the Ergo-One transaxle drive system. The drive system consists of a maintenance free transaxle drive driven by a powerful 24-volt motor. Maintenance free batteries, solid-state electronics and an automatic charging system make the Lakeside Ergo-One Plus Power carts are the durable and worry free solution to your transport needs. Decrease the chances of serious injury. Fingertip controls allow for one-hand operation. Features a rugged suspension system and emergency stop.

PRODUCT INFORMATION

Capacity (lbs)	1500
Material	Powder Coated Steel
Country of Origin	US
Platform Height (in)	11.5
Handles	1
Platform Size (in)	27 x 60
Caster Size-Front (in)	5
Caster Size-Rear (in)	8.75
Caster Size (in)	5

Caster Type 2 Ea. Fixed Powered, 4 Ea. Swivel

Overall Size (WxLxH) 27 x 68 1/2 x 43 1/2 in

SHIPPING DIMENSIONS

Weight 295 lbs 133.81 kgs

Dimensions 75 x 29 x 45 in 190.5 x 73.66 x 114.3 cm

[Add to Project](#)

Specification

Platform Truck, Ergo-One® Plus Power™, battery operated, intuitive finger tip controls, 1500lb capacity, sealed AGM maintenance free batteries, onboard CSA/UL certified charger with cord, solid-state electronics, anti-skid deck mat, 24-volt motor, platform size 27" x 60", (4) 5" swivel casters, (2) 8-3/4" power wheels, Made in USA